

6 STRIKE LOCATOR
PLACE THIS EDGE
AGAINST DOOR STOP



DRILL 1" (25mm) DIA.
HOLE 5/8" (16mm) DEEP
INTO DOOR JAM

3 MARK CENTER
OF HOLE
ON DOOR FACE

4 DRILL 2 1/8"
(54mm) HOLE

2 3/4"
BACKSET

2 1/8" (54mm) hole.

2 3/8" (60mm)
BACKSET

TEMPLATE
FOR INSTALLING KNOBSET



5 DRILL 1" (25mm) HOLE IN
CENTER OF DOOR EDGE
FOR RECTANGULAR LATCH
OR ROUND FACE

PK-130046

PLACE TEMPLATE FOLD ON EDGE OF DOOR SWINGING AWAY FROM THE FRAME

IMPORTANT!